TRUE-TRACK, INC."



Front Isolator - OEM PN 16207-79D
Fitment years 1980-2008
No longer sold by True-Track — buy direct at HD

Follow the Harley shop manual instructions for proper installation. TIP: Flat washer side goes towards top against engine plate.