



20-92 "TRUE-ISOLATOR" Front

Follow the Harley shop manual instructions for proper installation.

TIP: Flat washer side goes towards top against engine plate